



# Flame Tracker\* Dry

*Dry SiC Flame Sensor*

**Reuter-Stokes**

**Operation and Maintenance Manual**

**FS-9009OM Rev. M  
March 2018**

[www.gemeasurement.com](http://www.gemeasurement.com)

\* A trademark of Baker Hughes, a GE company, LLC  
©2018 Baker Hughes, a GE company. All rights reserved.  
Technical content subject to change without notice.

## Notice

All content and material in this Manual (including, without limitation, text, design, graphics, logos, icons, images, code and software, as well as the selection and arrangement thereof) is confidential and proprietary, the exclusive property of and owned by Reuter-Stokes, LLC. and is protected by copyright, trademark and other applicable laws. Any use of content and material in this Manual, including but not limited to the modification, distribution, transmission, performance, broadcast, publication, uploading, licensing, reverse engineering, transfer or sale of, or the creation of derivative works from, any material, information, software, products or services obtained from the content and material in this Manual, or use thereof for purposes competitive to Reuter-Stokes, LLC, is expressly prohibited.

WHILE EVERY ATTEMPT HAS BEEN MADE TO ASSURE THE COMPLETENESS, ACCURACY AND TIMELINESS OF THE CONTENT AND MATERIAL IN THIS MANUAL, IT IS PROVIDED ON AN "AS IS" AND "AS AVAILABLE" BASIS. REUTER-STOKES, LLC. EXPRESSLY DISCLAIMS ALL WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND ANY WARRANTIES THAT THE CONTENT AND MATERIAL IN THIS MANUAL IS NONINFRINGEMENT, AS WELL AS WARRANTIES IMPLIED FROM A COURSE OF PERFORMANCE OR COURSE OF DEALING; THE MATERIALS IN THIS MANUAL WILL BE ERROR-FREE; OR THAT THE MATERIALS IN THIS MANUAL WILL BE COMPLETE, ACCURATE OR TIMELY. NO ADVICE OR INFORMATION, OBTAINED BY YOU FROM REUTER-STOKES, LLC. OR THROUGH THE CONTENT AND MATERIAL IN THIS MANUAL SHALL CREATE ANY WARRANTY OF ANY KIND. REUTER-STOKES, LLC. DOES NOT MAKE ANY WARRANTIES OR REPRESENTATIONS REGARDING THE USE OF THE CONTENT AND MATERIAL IN THIS MANUAL IN TERMS OF THEIR COMPLETENESS, CORRECTNESS, ACCURACY, ADEQUACY, USEFULNESS, TIMELINESS, RELIABILITY OR OTHERWISE.

YOU ACKNOWLEDGE AND AGREE THAT YOU ASSUME FULL RESPONSIBILITY FOR YOUR USE OF THE CONTENT AND MATERIAL IN THIS MANUAL. YOU ACKNOWLEDGE AND AGREE THAT YOUR USE OF THE CONTENT AND MATERIAL IN THIS MANUAL IS AT YOUR OWN RISK. YOU ACKNOWLEDGE AND AGREE THAT, TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, REUTER-STOKES, LLC. WILL NOT BE LIABLE FOR ANY DIRECT, INDIRECT, PUNITIVE, EXEMPLARY, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR OTHER DAMAGES ARISING OUT OF OR IN ANY WAY RELATED TO THE CONTENT AND MATERIAL IN THIS MANUAL, WHETHER BASED ON CONTRACT, TORT, STRICT LIABILITY OR OTHERWISE. THIS DISCLAIMER APPLIES, WITHOUT LIMITATION, TO ANY DAMAGES OR INJURY ARISING FROM ANY FAILURE OF PERFORMANCE, ERROR, OMISSION, YOUR LOSS OF PROFITS, DESTRUCTION, AND ANY OTHER TANGIBLE OR INTANGIBLE LOSS.

*Copyright © 2018 Baker Hughes, a GE company.*

*Contains Baker Hughes, a GE company Confidential Information.*

## Revision History

REVISION	DATE	ECN	AUTHOR
E	12/21/2015	500000199090	J. Hashmi
F	02/22/2016	500000204318	J. Hashmi
G	10/10/2016	500000226345	J. Hashmi
H	12/07/2016	500000236444	R. Austin
J	08/09/2017	500000258146	J. Hashmi
K	09/27/2017	500000263564	J. Hashmi
L	11/03/2017	500000272164	J. Hashmi
M	03/22/2018	500000285626	V. Rubino

## Information and Safety Paragraphs

**Note:** *These paragraphs provide information that provides a deeper understanding of the situation, but is not essential to the proper completion of the instructions.*

**IMPORTANT:** *These paragraphs provide information that emphasizes instructions that are essential to proper setup of the equipment. Failure to follow these instructions carefully may cause unreliable performance.*

**CAUTION!** These paragraphs indicate a risk of potential minor personal injury and/or severe damage to the equipment, unless these instructions are followed carefully.

**WARNING!** These paragraphs indicate a risk of potential serious personal injury, unless these instructions are followed carefully.

## General Safety Issues

The user must make sure to operate all auxiliary equipment in accordance with local codes, standards, regulations, or laws applicable to safety.

**WARNING!** Do not disconnect the sensor while the circuit is energized (live), unless the area is known to be non-hazardous and free of explosive gases.

**CAUTION!** The **Flame Tracker Dry** is designed to operate at extreme temperatures. Do not attempt to work on the **Flame Tracker Dry** until it has reached a safe handling temperature.

## Certification Information

**ATTENTION!** The RS-FS-9009-XX **Flame Tracker Dry** sensor complies with the following standards:


ETL



**Intertek** Control Number 9900287

Class 1, Div. 2, Grp A,B,C,D T3  
Class 1, Zone 2 AEx nA IIC T3 Gc

ATEX / IECEx



Ex nA IIC T3 Gc

Hot End

$-51^{\circ}\text{C} \leq T_a \leq 190^{\circ}\text{C}; T3$

$-51^{\circ}\text{C} \leq T_a \leq 285^{\circ}\text{C}; T2$

$-51^{\circ}\text{C} \leq T_a \leq 325^{\circ}\text{C}; T1$

Cool End

$-51^{\circ}\text{C} \leq T_a \leq 150^{\circ}\text{C}; T3$



China Hazardous  
area mark



Customs Union  
Hazardous area mark



South Korea KTL  
hazardous area mark



Brazilian INMETRO  
Hazardous area mark

These certifications are based on the use of approved interconnecting cables only. Currently available approved interconnecting cables are BHGE Reuter Stokes RS-E2-0285PXXX and GE 362A1053PXXX. See Section 1.3 for details.

## Table of Contents

<b>1 Introduction</b> .....	<b>1</b>
1.1 General Description.....	1
1.2 FLAME TRACKER DRY COOL & HOT END (RS-FS-9009-03).....	1
1.3 Interconnecting Cable (RS-E2-0285PXXX).....	2
1.4 Flame Tracker Dry Specifications (RS-FS-9009-XX).....	3
<b>2 Installation</b> .....	<b>4</b>
2.1 Routing the Sensor Cable.....	4
2.2 Cool End Installation.....	7
2.3 Hot End Installation.....	8
<b>3 Setup</b> .....	<b>10</b>
3.1 Wiring to the Controller.....	11
3.2 Controller Setup.....	12
3.3 Sensor Functional Check.....	12
<b>4 Sensor Removal</b> .....	<b>13</b>
<b>5 Maintenance</b> .....	<b>13</b>
<b>6 Troubleshooting</b> .....	<b>14</b>


# 1 Introduction

## 1.1 General Description

The **Flame Tracker Dry** is an ultraviolet (UV) light sensitive detector used to measure the intensity of the flame in the combustion chambers of a gas turbine. Due to the use of a silicon carbide photodiode, the **Flame Tracker Dry** is very sensitive to the longer wavelength components of the UV light generated by the flame. These wavelengths penetrate the fog of fuel in the combustion can so the **Flame Tracker Dry** is significantly more sensitive to the flame than previous technologies, such as Geiger Mueller tubes. Being a UV sensitive device, the **Flame Tracker Dry** is not sensitive to the visible and infrared light generated by the hot combustion chamber walls so only the flame's light is detected.


The **Flame Tracker Dry** also separates the UV light sensitive photodiode in the *Hot End*, mounted on the combustion cans, from the temperature sensitive electronics in the *Cool End*, mounted below the turbine in a cool zone. This allows the **Flame Tracker Dry** to be operated indefinitely without the use of a cooling system. The single unit cannot be modified or disassembled. Any modifications will void the warranty and will cause an unsafe condition.

## 1.2 FLAME TRACKER DRY COOL & HOT END (RS-FS-9009-03)



Dimensions in inches [millimeters]  
 Dimensions are for reference only

### 1.3 Interconnecting Cable (RS-E2-0285PXXX)



Connector : MIL-DTL-38999 series III, shell size 15, 5 #16 pins  
 Voltage (max) : 300 VRMS  
 Temperature (max) : 482°F (250°C)

Dimensions in inches [millimeters]  
 Dimensions are for reference only

Interconnecting Cable Part Number	Total Length ft [m]	Armor Length in [cm]	Connector Type
RS-E2-0285P001	60-62 [18.3-18.9]	36 [14.2]	Right Angle
RS-E2-0285P002	60-62 [18.3-18.9]	None	Right Angle
RS-E2-0285P003	60-62 [18.3-18.9]	75 [190.5]	Right Angle
RS-E2-0285P004	120-122 [36.6-37.2]	36 [14.2]	Right Angle
RS-E2-0285P005	70-72 [21.3-22.0]	36 [14.2]	Right Angle
RS-E2-0285P007	39-41 [11.9-12.50]	36 [14.2]	Right Angle
RS-E2-0285P011	60-62 [18.3-18.9]	36 [14.2]	Straight
RS-E2-0285P012	120-122 [36.6-37.2]	36 [14.2]	Straight
RS-E2-0285P017	39-41 [11.9-12.50]	36 [14.2]	Straight



## 1.4 Flame Tracker Dry Specifications (RS-FS-9009-XX)

### Mechanical

Hot End Pipe Union:	300 Series Stainless Steel
Hot and Cool End Housings:	300 Series Stainless Steel
Hot End Mount:	3/4" NPT female, 2-1/4" Union Nut
Cool End Mount:	2-1/2" Pipe Clamp for 1-5/8" Strut Channel
Connectors:	
Cool End to Interconnecting Cable:	MIL-DTL-38999 Series III size 15 (5 pin)
Sensor:	Silicon Carbide photodiode
Window:	Sapphire

### Operating

Sensitivity:	>5 mA @ $1 \times 10^{10}$ photons/in <sup>2</sup> /sec @ 310 nm
Output:	Operating: 4 - 20 mA, Max < 21 mA
Response time:	<175 milliseconds
Power Requirements:	
Cool End:	12 - 30 VDC @ > 100 mA
Interconnecting Cable:	Max voltage 300 Vrms
Temperature Range:	
Hot End:	-60°F to 617°F (-51°C to 325°C)
Cool End:	-60°F to 284°F (-51°C to 140°C) Operating -60°F to 302°F (-51°C to 150°C) Short Duration with 150 C Shutdown
Interconnecting Cable:	-60°F to 482°F (-51°C to 250°C)
Relative Humidity:	100%
Process Pressure:	400 psig (2.8 MPa)
Vibration:	
Hot End:	0.0125" Double Amplitude; 10 – 88 Hz 5 G continuous; 88 – 1200 Hz
Cool End:	IEC 60068-2-64 Spectrum A.2, Category 3

## 2 Installation


**IMPORTANT:** Do not install a flame sensor that has a cracked window, damaged threads, or one that has been disassembled.

Maintain a minimum bend radius of 6 inches for all bends of the MI cable.

Store sensors in shipping container provided. Keep in plastic bag with desiccant, the dust cap is to remain installed on the Cool End connector until time of installation.


### 2.1 Routing the Sensor Cable

The *Hot End* of the **Flame Tracker Dry** is mounted onto the sight tubes of the combustion cans. The *sensor cable* is mounted along the strut channel around the turbine. The *Cool End* is mounted on the I-beam or pedestal below the turbine. See the image below for an example installation on a Frame 7F turbine.



**Note:** Guide the Cool End down to the Cool End mounting location. Use care in handling the Cool End during the installation process to protect the electronics located inside the Cool End.


### Example 7EA Turbine Detector and Cable Routing




Mount the *sensor cable* to the strut channel using 1/8" cushioned loop clamps. A silicone cushion is recommended for its high temperature resistance. See the images below for the recommended cable mounting.

**IMPORTANT:** *The cable must be secured at least every 3ft. The minimum bend radius of the cable is 6 inches.*

1. Place the loop clamp on the *sensor cable* and position it over the opening in the strut channel.




2. Place the mounting nut in the strut channel and secure the installation using a bolt.



At the *Cool End*, the extra cable should be looped and mounted to a nearby strut channel using any convenient means. A secure mounting is required to prevent the *sensor cable* from rubbing due to turbine vibration. An appropriately sized pipe clamp for the size of the loops is recommended.

## 2.2 Cool End Installation

The *Cool End* is to be mounted below the turbine on the pedestal or I-beam on F-Class gas turbines or under the foot grating on E-Class gas turbines. Mount the *Cool End* to the strut channel using a 2-1/2" pipe clamp.




1. Mount the *Cool End* on a 1-5/8" strut channel using 2-1/2" pipe clamp.
2. Attach the *interconnecting cable* to the large connector on the bottom of the cold end as shown above. Spin the coupling nut on the connectors until the blue line on the cable connector completely covers the red line on the housing connector. This indicates the connectors are fully engaged.
3. The *interconnecting cable* has a short armored section after the connector. The rest of the *interconnecting cable* is not armored and must be routed through conduit for protection. The conduit must be grounded. Ensure that only the armored cable section protrudes from the conduit. Reference *section 1.3* for armored cable specifications.
4. The strut channel used for mounting the Cold Ends (electronics) must also be grounded.

**IMPORTANT:** Do not use excessive torque when mating these connections as connector damage may result. The connectors should be engaged by hand without the use of tools.

**Note:** Do not discard the protective caps covering the connectors as they will be reinstalled to prevent damage to the connectors during maintenance outages.


## 2.3 Hot End Installation

1. Before installing the *Hot End* onto the sight tube, perform a sensor functional check per *Section 3.3*. The flame sensor is installed to the sight tube using a pipe union. The pipe union consists of a 2-1/4" union nut, a male-end to be installed on the sight tube, and a female end that is integral to the flame sensor. To avoid damage to the sensor and the *sensor cable*, two wrenches must be used when installing the *Hot End* onto the sight tube. See the installation and removal steps below.
2. Apply a small amount of NEVER-SEEZ, PART NO NG-165 to the external threads of union nut and the threads of the sight tube prior to installing the Hot End of the flame sensor. Be sure the NEVER-SEEZ applied to both parts is minimal and only applied below the 2<sup>nd</sup> thread. If NEVER-SEEZ is applied to the face of the sight tube or union nut, upon heating, it can fog the window of the flame sensor and reduce output.
3. Inspect the window and clean with an isopropanol-soaked swab, if required. Tighten female pipe union onto the sight tube to 90 ft-lbs using a 1-5/16" wrench. Install Hot End hand tight. Use the 1-5/16" wrench to hold the female pipe union. Tighten the union nut 120 ft.-lbs. using a 2-1/4" wrench.
4. Tighten *male pipe union* onto the sight tube to 90 ft.-lbs. using a 1-5/16" wrench.




Remove NEVER-SEEZ from faces of the sight tube and *male pipe union* mounting on *Hot End*

5. Tighten the *union nut* to the *male pipe union* by hand.



6. Use a 1-5/16" wrench to hold the *male pipe union*. Tighten the *union nut* 120 ft.-lbs. using a 2-1/4" wrench.



7. To temporarily remove the hot end from the sight tube, reverse the instructions in *Section 2.3.6*. The male pipe union may be left on the sight tube. Remove the MI cable from a sufficient number of strut channel clamps and coil up the section of the hot end that is over the turbine. Tie up the coiled hot end and place to the side during outage activities.

**WARNING!** *The flame sensor seals high pressures within the turbine. The union nut must be tightened to the specified torque. Insufficient torque could result in combustion gases being released into the turbine compartment.*

*Do not wrench on the sensor body. Only apply wrenches to the hexagonal male pipe union and union nut. Wrenching on the sensor body may cause hot end disassembly and damage and can result in the malfunction of the sensor.*

**IMPORTANT:** *Union nut self-aligns the flame sensor body to the site tube. The union nut must be tightened to the specified torque. Insufficient torque could result in poor flame sensor sensitivity.*

### 3 Setup

Figure 1 is a block diagram of the **Flame Tracker Dry**. Inside the *Hot End* assembly a lens focuses UV light from the combustion reaction onto a silicon carbide photodiode, which converts it into an electrical current in proportion to the intensity of the UV light. The photodiode is connected, via the *sensor cable*, to an amplifier in the *Cool End* assembly. The amplifier has a high initial gain, which automatically shifts to a lower gain in order to accommodate a wide range of input light levels without saturating. The sensor regulates the supply current in proportion to the intensity of the UV light. Both power and signal are transmitted on the same two wires on the output of the *Cool End*. The sensor can be powered from a DC voltage between 12 and 30 volts.




Figure 1: Flame Tracker Dry SiC Block Diagram



### 3.1 Wiring to the Controller

The sensors are connected to the turbine junction box with *interconnecting cable* RS-E2-0285PXXX or GE engineering approved equivalent. The RS-E2-0285PXXX consists of black, white and green wires twisted and shielded.

**IMPORTANT:** *All interconnecting cables must be in grounded conduit. The green wire must be connected to earth ground at the junction box. Do not connect the shields to each other or to earth ground at any location. The shields should be individually jumped through all junction boxes and connected to the proper ground terminal at the controller.*

The polarity of the *interconnecting cable* is as follows; white is positive and black is negative/signal return. Reverse polarity will not damage the sensor, but will prevent it from operating. Signal cables from the junction box to the controller should be 18 gauge (1.02 mm) twisted shielded pair. The extension cable from the junction box to the controller is the customer’s responsibility.

The **Flame Tracker Dry** is connected to the controller as a typical two wire current transmitter. It can be operated from any well-filtered DC supply from 12 volts to 30 volts. The nominal operating voltage is 24 VDC and the power supply should be capable of providing 100 milliamps.

The power supply must be protected to prevent the supply voltage from exceeding 30 volts in normal use and more than 42 volts under transient conditions. The maximum value for the sense resistor plus the wire resistance is dependent on the supply voltage. At 24 volts this value is 560 ohms. Resistance values for other voltages can be determined from the chart in *Figure 2*.




Figure 2: Maximum Resistance vs. Operating Voltage

*Figure 1* shows the preferred wiring for the sensor with the  $R_{sense}$  of the controller in the return line of the sensor. This configuration can be used with controllers that have single ended inputs (one side of the input grounded) or differential inputs (neither side of the input grounded). For the interconnecting cable pinout see *Table 1* and reference *Figure 1*.

**Table 1: Interconnecting Cable Pinout**

PIN	CIRCUIT DESIGNATION	WIRE COLOR for RS-E2-0285PXXX cable
A	-	Black
B	+	White
C	Ground	Green
D	Not Used	
E	Not Used	

## 3.2 Controller Setup

The **Flame Tracker Dry** provides a minimum output of 5.0 milliamps when exposed to the minimum flame intensity specified in *Section 1.4*. The set point for “flame off” should be set to 6.25%, which equals 5.0 milliamps. The set point for “flame on” should be 12.5%, which equals 6.0 milliamps.

## 3.3 Sensor Functional Check

**WARNING!** Do not disconnect the sensor while the circuit is energized (live), unless the area is known to be non-hazardous and free of explosive gases.

**CAUTION!** The **Flame Tracker Dry** is designed to operate at extreme temperatures. Do not attempt to work on the **Flame Tracker Dry** until it has reached a safe handling temperature.

Disconnect the sensors and unscrew the *Hot Ends* from the turbine, **being careful to use two wrenches on the union nut to avoid spinning of the sensor**. Plug the *interconnecting cables* back in to each of the *Cool Ends*. Apply power to the sensors. Check the current values at the controller for each of the sensors. The sensors are sensitive to light, and may have some reading, depending on the ambient light level.


Test each sensor by covering the window to see the “flame off” reading. The “flame off” reading should be 3.60 to 4.25 milliamps. Next, test the “flame on” reading with a flashlight with an incandescent bulb. With most flashlights the reading should be above 8.0 milliamps. An LED flashlight may not work for this application. **UV Inspection flashlights with a UV wavelength between 245nm-365nm work best.** Variations in flashlight type, strength, or battery voltage may cause variation in signal output. The flashlight test is intended as a field test for general functionality only and is not a controlled or quantitative test. If a sensor is outside these rough check limits, see *Section 6*.

Disconnect the *interconnecting cables* and make sure that the sapphire windows in the *Hot End* assemblies are clean. If they need cleaning, do so according to the maintenance instructions in *Section 0*. Reinstall the sensors according to instructions in *Section 2*. After reinstallation, verify with the controller that all sensors still output between 3.60 and 4.25 milliamps under “flame off” conditions.

## 4 Sensor Removal

To remove the sensor reverse the installation process from *Section 2.3*.

**WARNING!** Do not wrench on the sensor body. Only apply wrenches to the hexagonal male pipe union and union nut. Wrenching on the sensor body may cause hot end disassembly and damage and can result in the malfunction of the sensor.



## 5 Maintenance

**WARNING!** Do not disconnect the sensor while the circuit is energized (live), unless the area is known to be non-hazardous and free of explosive gases.

**CAUTION!** The **Flame Tracker Dry** is designed to operate at extreme temperatures. Do not attempt to work on the **Flame Tracker Dry** until it has reached a safe handling temperature.

Do not remove the sensor by wrenching on the body. Always use the 2-1/4" union nut. Wrenching on the body may breach the seal. Breaching the seal of the sensor will cause loss of the inert fill gas and render the sensor unusable. Once the seal has been broken it cannot be resealed.

Do not attempt to disassemble the sensor. Sensor is not repairable. Once the seal has been broken it cannot be resealed.

The **Flame Tracker Dry** output will deteriorate as the sapphire window becomes dirty. It is recommended, when initially installed, that the signal level be recorded during normal operation. During subsequent operation, the signal level should be compared with the initial values. If a significant reduction in the signal level is noticed, it is recommended that the window be cleaned at the next opportunity (with the turbine shut down and cold). Clean the window with isopropyl alcohol or other residue free solvent compatible with sapphire, stainless steel and gold.

## 6 Troubleshooting

**WARNING!** Do not disconnect the sensor while the circuit is energized (live), unless the area is known to be non-hazardous and free of explosive gases.

**WARNING!** The *Flame Tracker Dry* is designed to operate at extreme temperatures. Do not attempt to work on the *Flame Tracker Dry* until it has reached a safe handling temperature.

**Table 2: Flame Sensor Problems and Solutions**

Problem	Cause	Solution
No 4mA – 20mA output signal	<ol style="list-style-type: none"> <li>1. Reversed polarity</li> <li>2. Open I/O connections</li> <li>3. No power from the 12-30V supply</li> <li>4. Interconnecting cable has failed</li> </ol>	<ol style="list-style-type: none"> <li>1. Change polarity at junction box or flame sensor module (Mark V and below).</li> <li>2. Check connections at junction box, flame sensor module (Mark V and below), and Cool End.</li> <li>3. Check voltage supply to ensure power is reaching sensor.</li> <li>4. Replace interconnecting cable.</li> </ol>
Low sensitivity during sensor functional check	<ol style="list-style-type: none"> <li>1. Hot End window is dirty</li> <li>2. Grounded Cable</li> <li>3. Union nut not torqued</li> </ol>	<ol style="list-style-type: none"> <li>1. Clean window per <i>Section 0</i>.</li> <li>2. Verify earth ground and shield are properly connected.</li> <li>3. Check torque, torque to specified values.</li> </ol>
Low flame intensity signal during operation	<ol style="list-style-type: none"> <li>1. Sensor line of sight is obscured</li> <li>2. Hot End window is dirty</li> <li>3. Hot End is not mounted straight in the pipe union</li> </ol>	<ol style="list-style-type: none"> <li>1. Check straightness of sight tube. Verify combustion chamber liner doesn't block sight tube opening.</li> <li>2. Clean window per <i>Section 0</i>.</li> <li>3. Loosen union nut and realign Hot End. Ensure union nut is retightened to 120 ft.-lbs.</li> </ol>
Periodic low reading on secondary flame sensor locations of DLN1 turbines	<ol style="list-style-type: none"> <li>1. Condensation on the sensor window that can occur under high humidity situations.</li> </ol>	<ol style="list-style-type: none"> <li>1. A shorter mount tube (PN# E1-0058P002), available from BHGE Reuter Stokes may improve this condition. Please contact BHGE Reuter Stokes for further information.</li> </ol>
No flame indication	<ol style="list-style-type: none"> <li>1. Flame sensor not plugged into interconnecting cable or Controller.</li> <li>2. Open I/O connection and No power from the 12-30V supply</li> <li>3. Interconnecting cable has failed</li> </ol>	<ol style="list-style-type: none"> <li>1. Check connections at junction box, interconnecting cable, and flame sensor (Mark V and below).</li> <li>2. Check voltage supply to ensure power is reaching sensor.</li> <li>3. Replace interconnecting cable.</li> </ol>




Figure 3: Mark V and Below Control System Troubleshooting Flow Diagram




Figure 4: Mark VI and Greater Control System Troubleshooting Flow Diagram

[no content intended for this page - proceed to next page]

## Customer Support Center

Baker Hughes, a GE company  
Reuter Stokes Measurement Solutions Products  
8499 Darrow Road  
Twinsburg, OH, 44087 USA

Tel: +1-330-425-3755

[www.gemeasurement.com/quality-certifications](http://www.gemeasurement.com/quality-certifications)

[www.gemeasurement.com](http://www.gemeasurement.com)

©2018 Baker Hughes, a GE company. All rights reserved.  
Technical content subject to change without notice.