

マイクロSD・マイクロSDHC携帯電話対応表

Softbank

メーカー	携帯機種名	マイクロSD		マイクロSDHC	
		1GB	2GB	4GB	8GB
SHARP	941SH	○	○	○	○
	940SH	○	○	○	○
	935SH	○	○	○	○
	934SH	○	○	○	○
	933SH	○	○	○	○
	932SH	○	○	○	○
	931SH	○	○	○	○
	930SH	○	○	○	×
	923SH	○	○	○	×
	922SH	○	○	○	×
	921SH	○	○	○	×
	920SH	○	○	×	×
	913SH	○	○	×	×
	912SH	○	○	×	×
	911SH	○	×	×	×
	910SH	○	×	×	×
	840SH	○	○	×	×
	832SH s(GENT)	○	○	○	○
	832SH	○	○	○	○
	831SH s(GENT)	○	○	○	○
	831SH	○	○	○	○
	830SH for Biz	○	○	○	×
	830SH s(GENT)	○	○	○	×
	830SH	○	○	○	×
	825SH	○	○	○	×
	824SH	○	○	○	×
	823SH	○	○	×	×
	822SH	○	○	×	×
	821SH	○	○	×	×
	820SH	○	○	×	×
816SH	○	○	×	×	
815SH	○	○	×	×	
814SH	○	○	×	×	
812SHs	○	○	×	×	
812SH	○	×	×	×	
811SH	○	×	×	×	
810SH	○	×	×	×	
Panasonic	940P	○	○	○	○
	931P	○	○	○	○
	930P	○	○	○	○
	921P	○	○	○	×
	920P	○	○	○	×
	840P	○	○	×	×
	832P	○	○	○	○
	831P	○	○	×	×
	830P	○	○	×	×
	824P	○	○	○	×
	823P	○	○	○	×
	822P	○	○	○	×
	821P	○	○	×	×
	820P	○	○	×	×
	810P	○	○	×	×
	706P	○	○	×	×
	705P	○	○	×	×
TOSHIBA	921T	○	○	×	×
	920T	○	○	×	×
	912T	○	○	×	×
	911T	○	○	×	×
	832T	○	○	×	×
	831T	○	○	○	○
	830T	○	○	○	○
	824T	○	○	×	×
	823T	○	○	×	×
	822T	○	○	×	×
	821T	○	○	×	×
	815T	○	○	×	×
	814T	○	○	×	×
	813T	○	○	×	×
	812T	○	×	×	×
	811T	○	×	×	×
	810T	○	×	×	×
X02T	○	○	○	○	
HTC	X05HT	○	○	○	○
サムスン電子	940SC	○	○	○	○
	931SC	○	○	○	○
	930SC	○	○	○	○
	920SC	○	○	×	×
	830SC	○	○	○	○
	821SC	○	○	○	×
	820SC	○	○	×	×
	805SC	○	○	×	×
	740SC	○	○	○	×
	731SC	○	○	○	×
	709SC	○	×	×	×
	708SC	○	×	×	×
	706SC	○	×	×	×
	705SC	○	×	×	×
	X01SC	○	○	○	○